

# Standalone Roof laser



## Kit parts



Relay box




Laser sensor



Horness kit

## Mounting

Install the laser sensor on the rooftop of the truck. It's possible to install this sensor on any kind of machines.



# Electrical connection

